



Installation Guide

- Select correct size Ridge Anchor for tile profile (4", 5", 6", 7", 8").
- Fasten Ridge Anchor to substrate with 1 1/2" self-sealing screw (16" o/c) or approved roof nail (6" o/c). Apply approved sealant if fastener is not self-sealing.
- Complete installation of field cut tile and apply approved mortar for weather blocking.
- Apply adhesive foam along top of Ridge Anchor or on underside of hip/ridge tile.
- Attach hip/ridge tile to Ridge Anchor with an approved roof tile fastening screw (minimum #8 x 2 1/2" course thread).
- Apply adhesive foam on head lap of hip/ridge tile (Tile Bond only).

Hip / Ridge Resistance Values

Tile Profile	Attachment	Adhesive Amount	Allowable Overturn Moment (ft-lbf)
Hip / Ridge	Polyfoam AH160 / Screw	2" x 8" Paddy (no foam on headlap)	198
Hip / Ridge	Tile Bond / Screw	2" x 8" Paddy 1" x 8" on headlap	132